

## Tools

1. Sharp blade  
(Carpet knife)
2. Floor cleaner  
(plastic cleaner or  
isopropanol)
3. Wide crepe-tape

## Tutorial

You can find an installation tutorial at [www.seadek.de/bestellen/](http://www.seadek.de/bestellen/) or <https://youtu.be/NN9VDgMmAB0>

SeaDek Certified Fabricator  
Otto-Wallach-Straße 12  
65203 Wiesbaden  
[seadek@seadek.de](mailto:seadek@seadek.de)  
[www.seadek.de](http://www.seadek.de)

## Storage

SeaDek® should be stored in a cool, dry, indoor area until it is installed.

## Installation restrictions

1. Do not install SeaDek® at temperatures below 15°C.
2. After installation, do not attempt to loosen SeaDek® to correct the position.
3. The contact pressure on the attached material should be 2 kg per cm<sup>2</sup> to fully activate the adhesive.
4. The adhesive will develop about 80% adhesion in about 20 hours. Please keep the product away from water during this time.

## Preparation

1. Use a floor cleaner / plastic cleaner for pre-cleaning, then use isopropanol to re-clean the surface where SeaDek® is to be applied. Please clean carefully.
2. Make sure that all grease, adhesives, mold release agents, wax and other substances have been removed before installing SeaDek®. The surface must be completely dry before adhering the pads.

## Installation

1. Before peeling off the backing film, place the pads on the surface to check the fit and spacing and to determine the exact position of the pads.
2. Turn the pad over so that the backing film is facing up. Using a sharp knife, cut the backing film in half. Take a narrow spot for this purpose. Be sure to cut completely through the backing film, but do not cut into the pad.
3. Fold over a piece of the backing film on both sides to expose the adhesive surface in the center.
4. Turn the pad over again and position it exactly where you want to install it. And press lightly on the pad to fix the open adhesive area.
5. Fix one side of the pad with adhesive tape. Taping prevents the pad from moving.
6. Now lift the non-fixed side and slowly and carefully peel off the rest of the backing film from the center towards the outer edges while applying the pad. Apply pressure to the product to ensure that there is a firm bond between the pad and the surface. Note: Please do not pull or stretch the pad!
7. Remove the tape from the other side of the pad and repeat step 6.
8. Press firmly on all surfaces and edges of the pad to ensure even adhesion.
9. Press all edges firmly and check the tight fit again after 10 min.

PS: Show us the final result. We look forward to receiving your personal SeaDek® photos! 😊

# Installation Guide